

**NKØE's Yeasu VX-2R Quick Reference**

**VFO**  

 KHz MHz Band Up Band Down

**VFO Scan**  

 BAND hold BW release change scan dir stop scan

**Squelch**  

 FW MONI level PTT TX Power H/L toggle H/L power

**Tone**  

 FW MD type PTT Wx / SW / Marine FW BAND toggle

**Tone Frequency**  

 H/L menu 44 H/L freq H/L 1 sec

**VFO >> Memory**  

 FW mem# FW

**Memory >> VFO**  

 FW V/M 1 sec

**Memory Scan**  

 BAND hold mode release stop scan MD

AM / FM / WFM

**NKØE's Yeasu VX-2R Quick Reference**

**Menu Settings**  

 H/L 1 sec menu # H/L setting H/L 1 sec

1 Auto power off	25 Keypad lock
2 ARTS beep	26 MONI function
3 ARTS interval	27 Mem ch store select
4 Auto repeater shift	28 Name/frequency toggle
5 RX attenuator	29 Memory name
6 Busy channel lockout	30 Power-on message
7 Keypad beep	31 Scan resume mode
8 CTCSS/DCS bell rpt	32 RF squelch level
9 Busy LED	33 Repeater shift direction
10 CH counter width	34 Receive mode
11 CPU clk freq shift	35 Rx battery save interval
12 CW ID	36 Smart search mode
13 DC supply voltage	37 Scan lamp on/off
14 DCS mode	38 Repeater shift size
15 DCS inverted dcdng	39 Mem scan chnl mode
16 Display brightness	40 Split CTCSS/DCS
17 DTMF dialer mem #	41 Squelch level
18 DTMF programming	42 Tone squelch mode
19 Band edge beep	43 Tuning step size
20 Emergency alarm	44 Tone frequency
21 Reduce dev 50%	45 Time-out timer time
22 HM/RV function	46 TX battery saver
23 Internet conn	47 VFO band edge limiting
24 Backlight mode	48 NOAA WX alerts